



RECOMMENDED MAINTENANCE CHECKLIST

EVERY 6 MONTHS

- Wheel bearing and brake check
- Roof inspection for damage, sealant and general condition.
- LP leak test, Set LP regulator if needed

ANNUALLY

- Remove wheel bearings, clean and inspect, repack with new grease, install with new seals. Clean, inspect and check brakes.
- Seal Tec leak test roof seams, front and rear caps, corner moldings for air leaks.
- Slide room maintenance, lubricate rails and gears, apply conditioner to rubber seals
- Air conditioner performance test and clean filter. LP leak test, Set LP regulator if needed
- Furnace tune up, cleaning
- Water heater tune up, cleaning
- Refrigerator tune up, cleaning
- Inspect 5th wheel hitch, tighten bolts
- Inspect weight distribution assembly and tighten bolts
- Basic de-winterize, flush water lines, check for leaks and install water heater plug.
- Winterize annually
- Annual spring maintenance special
- Slide-room adjustment or diagnosis
- Basic exterior wash of sidewalls and awnings

BI-ANNUALLY

- Complete RV wash, includes sidewalls, awnings and roof. Then roof conditioner is applied

AS NEEDED

- Basic exterior was of sidewalls and awnings
- Check electric brake controller test and 7 pin connector test
- Pre-trip inspection, check appliance operation, charge battery and test, check brake operation, lube step, stabilizer jacks and coupler



Gib's RV Superstore - Service Department
541-888-3424 • service@gibsrvsuperstore.com

